







# Tuner Pioneer TX1070




 Indicates the transistor section of an inherent resistor transistor.


 Indicates a transistor that does not have an inherent resistor.

Tuner Pioneer TX1070



1. RESISTORS.  
Indicated in R, 1/4W, 1/8W, 5% tolerance unless otherwise  
noted K, K, M, M, (F), 1%, (G), 2%, (K), 10%, (M), 20% tolerance

2. CAPACITORS.  
Indicated in capacity (μF)/voltage (V) unless otherwise noted  
p, pF. Indication without voltage is 50V except electrolytic capacitor.

3. VOLTAGE CURRENT.  
Indicated in V, DC voltage (V) at no input signal  
mV: Signal voltage at FM 400Hz+75kHz DEV.

4. OTHERS:  
Signal route.  
Adjusting point.

The mark found on same component parts indicates the importance of the safety factor of the part. There fore, when replacing, be sure to use parts of identical designation.